Permissions and Sensors

Chapter 8: Exploring Android App Permissions:

Permissions

- Permissions on a device control what your app can do and what it can't.
- They keep user data safe and stop apps from doing things they shouldn't.
- Some permissions allow access to data and actions because they pose very little risk to the user's privacy or the operation of other apps.
 - Such as INTERNET, VIBRATE
- To get permissions, you need to declared in AndroidManifest.xml and granted automatically.

Permissions

- While some other permissions grant access to user data or control over the device that could affect the user's privacy or the operation of other apps.
 - Such as ACCESS_FINE_LOCATION, READ_CONTACTS, CAMERA
- To get such permissions, you also need to declare in AndroidManifest.xml and must be requested at runtime.

1: Checking if the device is connected to the WIFI

• 1. Add the necessary permissions to your AndroidManifest.xml file:

<uses-permission android:name="android.permission.ACCESS_NETWORK_STATE"/>
<uses-permission android:name="android.permission.ACCESS_WIFI_STATE"/>



data, VPN), It contains several methods to check the network status,

details about active networks, or manage network connections.

• 2. Create a new Java class named WifiManagerUtil.java:

```
port android.content.Context;
 mport android.net.ConnectivityManager;
import android.net.NetworkInfo;
                                                                              Is a general-purpose method that provides
                                                                              access to various system-level services in
 ublic class WifiManagerUti
  Method to check if the device is connected to the internet via WiFi
                                                                              Android
public static boolean isConnectedToWifi(Context context) {
ConnectivityManager connectivityManager = (ConnectivityManager) context.getSystemService(Context.CONNECTIVITY_SERVICE);
NetworkInfo wifiNetwork = connectivityManager.getNetworkInfo(ConnectivityManager.TYPE_WIFI);
return wifiNetwork != null && wifiNetwork.isConnected();
                                                                                      constant that specifies which service we want to
                                                                                      retrieve. specify that you want the connectivity
                                                                                      service.
                                                              Is class responsible for managing network connections, (Wi-Fi, mobile
```

Note: the type Context, we normally used to access system services and resources.

1: Checking if the device is connected to the WIFI

• 3. Modify your MainActivity.java file:

```
import android.os.Bundle;
import android.widget.Toast;
import androidx.appcompat.app.AppCompatActivity;
public class MainActivity extends AppCompatActivity
@override
protected void onCreate(Bundle savedInstanceState) {
super.onCreate(savedInstanceState);
setContentView(R.layout.activity_main);
  Check if device is connected to WiFi
  (WifiManagerUtil.isConnectedToWifi(this)) {
showToast("Connected to WiFi");
 else {
showToast("Not connected to WiFi
  Method to show toast message
private void showToast(String message) {
Toast.makeText(this, message, Toast.LENGTH_SHORT).show();
```

```
import android.content.Context;
import android.net.ConnectivityManager;
import android.net.NetworkInfo;

lusage
public class WifiManagerUtil {
    // Method to check if the device is connected to the internet via WiFi
    lusage
    public static boolean isConnectedToWifi(Context context) {
        ConnectivityManager connectivityManager = (ConnectivityManager) context.getSystemService(Context.CONNECTIVITY_SERVICE);
        NetworkInfo wifiNetwork = connectivityManager.getNetworkInfo(ConnectivityManager.TYPE_WIFI);
        return wifiNetwork != null && wifiNetwork.isConnected();
}
```

1: The details of the above code

Importing necessary classes from the Android framew import android.net.NetworkInfo;

```
import android.content.Context;
import android.net.ConnectivityManager;
```

Declares a new Java class this case 'WifiManagerUt public class WifiManagerUtil {

Declare a method 'isConnectedToWifi' which takes a Context object as a parameter and returns a boolean value (true if connected to Wi-Fi, false otherwise). If the device is connected to the internet via WiFi usage public static boolean isConnectedToWifi(Context context) {

This retrieves the system service for connectivity (ConnectivityManager) using the provided Contex ConnectivityManager connectivityManager = (ConnectivityManager) context.getSystemService(Context.CONNECTIVITY_SERVICE);

This gets information about the network connected to the device. Specifically, it retrieves information about the Wi-Fi netyNetworkInfo wifiNetwork = connectivityManager.getNetworkInfo(ConnectivityManager.TYPE_WIFI);

This checks if wifiNetwork is not null and if it's connected. It then returns true if connected, false otherwisereturn wifiNetwork != null && wifiNetwork.isConnected();

2: Check if internet available or not

Is network is actually


connected

check if there is any active network info


available.

AndroidManifest.xm This informs that the app requires permission to access the internet. <uses-permission android:name="android.permission.INTERNET" /> The variable activeNetworkInfo MainActivity.java add this inside a setOnClickListener contains an object of type **NetworkInfo**. method if (IsinetworkAvailable()) { It (object) represents information about the current active network connection Toast.makeText(MainActivity.this, "Internet Connection Available", Toast.LENGTH SHORT).show(); on the device. else { Toast.makeText(MainActivity.this, "No Internet Connection", Toast.LENGTH SHORT).show(); It can include details such as the type of network (e.g., WIFI, mobile data), whether the device is connected to a Declare a method 'isNetworkAvailable()' which returns a boolean value. network. method for network avilability private boolean isNetworkAvailable() { initialize the ConnectivityManager object, allowing the app to check the device's network connectivity. ConnectivityManager connectivityManager = (ConnectivityManager) getSystemService(Context.CONNECTIVITY SERVICE); retrieves information about the device's active network connection. NetworkInfo activeNetworkInfo = connectivityManager.getActiveNetworkInfo(); If both conditions are true, the method returns true, indicating return activeNetworkInfo != null && activeNetworkInfo.isConnected(); that the network is available. Otherwise, it returns false.

3: Bluetooth permissions



3: Bluetooth permissions



4: Check if the device has a vibrator

AndroidManifest.xml •To access the device's vibrator service, we need this to declare, so that the app gives us permission to use the device's vibration <uses-permission android:name="android.permission.VIBRATE" /> functionality. •Without this permission, the app cannot access the device's vibrator. MainActivity.java add this inside a setOnClickListener method This is a method that returns a system-level service by name, in this case, the vibrator object can be used to control the service. device's vibration functionality. Vibrator vibrator = (Vibrator) getSystemService(Context.VIBRATOR_SERVICE); request the vibrator service. Is a method that returns true if the device has a vibrator, otherwise, it returns false. if (vibrator.hasVibrator()) { Toast.makeText(MainActivity.this, "Vibrator Available", Toast.LENGTH SHORT).show(); // Vibrate for 500 milliseconds vibrator.vibrate(500); else { Toast.makeText(MainActivity.this, "Vibrator Not Available", Toast.LENGTH SHORT).show();



Roles of Context and getSystemService

- The **qetSvstemService** method and the **Context** class play different roles but somehow interrelated.
- Context roles is to provides access to application-specific resources and classes, as well as information about the application environment.
- Some of the services and resources he can access include:
 - **Access Application Resources**: Retrieve resources, databases, and preferences.
 - Start Activities and Services: Launch activities, start and stop services.
 - Send Broadcasts: Send and receive broadcast messages across the system.
 - Access System Services: Obtain references to system-level services.
- The getSystemService method: is a method provided by the Context class that allows you to retrieve references to various system-level services.
 - Potriova System Sarviage such as connectivity location, consor

5: Checking for Accelerometer Availability

Giving the app the necessary permissions to access sensor data

<uses-permission android:name="android.permission.BODY_SENSORS" />

<u>Accelerometer, Gyroscope, Pedometer, Biometric Sensors and many more are</u> sensors that are <u>part of the broader category of Body Sensors</u>.

```
We use this method to get the SensorManager system service, which allows access to the device's
 Get the SensorManager service
SensorManager sensorManager = (SensorManager) getsystemService(Context.SENSOR_SERVICE);
                                                                 This constant is used to retrieve a reference to the SensorManager service.
  Check if the accelerometer is available
 (sensorManager != null) {
                               gets the default accelerometer sensor.
 Sensor accelerometer = sensorManager.getDefaultSensor(Sensor.TYPE_ACCELEROMETER);
 if (accelerometer != null) {
                                                                                                 Other Service types you can
   Toast.makeText(MainActivity.this, "Accelerometer Available", Toast.LENGTH SHORT).show();
                                                                                                 checkrype_gyroscope
  } else {
                                                                                                       TYPE MAGNETIC FIEL
    Toast.makeText(MainActivity.this, "Accelerometer Not Available", Toast.LENGTH SHORT).show();
                                                                                                       TYPE LIGHT
                                                                                                       TYPE PRESSURE
```

Sensors


TYPE ACCELEROMETER

- Accelerometer measures the acceleration applied to the device. Accelerometer helps confirm how you're holding your phone.
 - Detecting the orientation of the device (e.g., landscape or portrait mode).
 - Motion detection (e.g., shaking the device).
 - Step counting in fitness applications.
 - · Detecting free-fall scenarios.

TYPE_GYROSCOPE

- A gyroscope measures the rate of rotation around the device's three primary axes (x, y, and z).
 - Enhancing the accuracy of the accelerometer by providing rotational motion data.
 - Advanced gesture recognition.
 - Improving the orientation tracking for augmented reality applications.
 - Stabilizing the camera during video recording.





Sensors

TYPE_MAGNETIC_FIELD

- A magnetic field sensor and it helps your phone act like a compass, showing you which way is north.
 - · Implementing a digital compass.
 - Providing orientation data when combined with data from the accelerometer.
 - Augmented reality applications that require precise orientation information.
 - Navigation applications for determining direction.

TYPE LIGHT


- A light sensor measures the ambient light level (illumination) in lux.
 - · Adjusting the screen brightness automatically.
 - Conserving battery life by dimming the screen in low light conditions.
 - Enhancing user experience by adapting to the lighting environment.
 - Detecting if the device is in a pocket or bag.



Sensors

TYPE_PRESSURE

- This sensor measures the air pressure around vour device. It reports the pressure in units called hectopascals (hPa) or millibars (mBar).
 - Determining altitude or elevation changes for location-based applications (e.g., GPS navigation).
 - Weather forecasting applications:
 By measuring changes in air pressure, it help weather apps predict changes in the weather, like when a storm is coming.
 - Fitness applications: Measure how much you go up and down during activities like hiking or climbing.
 - Enhancing indoor navigation by identifying different floors in a building.





Any Question?